




RUBBER & NYLON PADS FOR TYRE CHANGERS





















1 551804


Bead Breaking Rubber Pad

Weight:	Code No.	Weight:	Code No.
830gms	551004	3.310kg	551804
430gms	551104	1.365kg	559004
355gms	556304	890gms	558004
455gms	556404	2.095kg	551404

Use: Used with Tyre Changing Machines to prevent scratches on rims during bead breaking.








35

RUBBER & NYLON PADS FOR TYRE CHANGERS













551704

2 Bead Breaking Rubber Pad	Weight: 1.620kgs	Code No. 551204
Protection Cover for Read Breaking	0.265kas	551204WPC

Rubber Pad 551204 Material: Special Plastic.

: It protects the wheel when using the shovel to loosen the bead

of the wheel

Note : 551204WPC protection cover fits on the bead breaking pad 551204.

3 Bead Breaking Rubber Pad	Weight: 1.310kgs	Code No 551304
Material : PU.	1.070kgs	556204
4 Large Bead Loosener Front Pad	(Nylon)	
	Weight:	Code No
	250gms	551504
5 Small Bead Loosener Front Pad	(Nylon)	
	Weight:	Code No
	195gms	551704
6 Large Centre Rubber Pad	Weight:	Code No
	1.195kgs	551604
	1.195kgs	531004
7 Centre Rubber Pad	Weight	Code No


Weight:

0.923kgs

Code No.

556104





MANUFACTURING AND EXPORTS TO 70+ COUNTRIES SINCE 1987



WORLDWIDE PRESENCE











Sarveshwari Engineers

355 Deepali, Pitampura, Delhi - 110 034 (INDIA) Tel.: 91-11-2702 3750, 91-11-2702 1499

Web: www.sarveshwari.com E-mail: info@sarveshwari.com





